Procon

MELCLOUD Cellular/LAN Interface
Ref: MELCLOUD-CL-HA1-A1

Quick start guide
V1

1

2A Switch off power to indoor/outdoor unit ⚠

2B Remove the cover of your indoor unit and follow instructions below to connect the interface depending on the type of unit

2C Plug end of cable into CN105/CN92 (red connector)

Air conditioning indoor unit

Heating cylinder indoor unit

Heating hydro box indoor unit

2D Route cable

2E Replace cover and switch power back on


3A
- Plastic type for use on plasterboard walls (2 pcs – included)
- To be used together with corresponding screw (40mm length)

Screw type (2 pcs – included):
Countersunk screw Philips head - M4x40

Centre distance: 45mm

FRONT

3B Mount externally from the indoor unit

4

Procon IoT Interface

UNIT
NETWORK
CLOUD
ERROR

RESET   MODE

⏻ > ⏱ 2 mins

It may take up to two minutes for the device to power ON and connect to the best cellular network when first powered up.

5

Procon IoT Interface

UNIT
NETWORK
CLOUD
ERROR

RESET   MODE

📶 > ⏱ 10 mins

On Solid: Communicating Successfully
Flashing every 2 Seconds (0.5Hz): Connecting
Flashing every 0.5 seconds (2Hz): Error

Label	LED	Status
UNIT	ON	Communicating with HVAC Unit
NETWORK	ON	Communicating with Internet
CLOUD	ON	Communicating with Cloud
ERROR	OFF	-

6

Download app MelCloud Home
www.melcloud.com/en/downloadapp

Settings

Change Mode:
Press and hold* the Mode button for more than 5 seconds to cycle through the modes (see table of modes)

Soft Reset:
Press and release* the Reset button

Factory Reset:
Press and hold the Reset button for 10 seconds

Table of modes

Cellular		LAN	
Label	LED	Label	LED
UNIT	ON	UNIT	ON
NETWORK	OFF	NETWORK	ON
CLOUD	OFF	CLOUD	OFF
ERROR	OFF	ERROR	OFF

Contact: Travellers Lane, Hatfield AL10 8XB, UK

After sales service: Please contact your local branch office